

CLMC Dishwasher

Dishwasher Preparation: Turn on dishwasher 30-45 minutes before use.

1. Close dishwasher by pulling lever down.
2. Turn bottom switch on.
3. Turn upper switch on.
4. Water heat up takes approximately 30 minutes.

Use of Dishwasher

1. Place dishes and bowls in green washing racks with spacers, glasses bottom side up in blue washing racks, and silverware in flat washing rack with no spacers.
2. Once in racks, rinse all silverware, cups, & dishes fairly thoroughly at sink next to dishwasher prior to run through dishwasher.
3. When running glasses through place an empty upside down rack on top of the filled glasses rack so that the water stream will not shoot the glasses out of the filled rack.
4. To run dishwasher, place rack in middle of dishwasher, close dishwasher & push START. The cycle will start and a green light will show while the dishwasher is running. When the green light goes off, the cycle is finished.
5. Run silverware flat 3 times through dishwasher cycle. Then place silverware in round baskets handles up and run a third time placing those baskets in the flat rack.
6. All items should be left to air dry (as it is more sanitary) but if time does not permit, careful towel-drying is appropriate.
7. Dishes and small bowls go in the rolling cart. Note that when dishes are not in the cart, the bowls are likely to fall over.
8. Glasses are stacked in blue racks on a rolling cart.
9. When done with all washing, switch off the dishwasher and fan.
10. Rinse and clean dish wash area.
11. Return dish and glass carts under countertops, silverware to drawers, and pots and pans to countertop or overhead storage.